

No.	Classification	Product name or code	
1	Counter	Natural stone/ ceramic/quartz/wood	
2	Sink	HS800	

	Package							
No.	Product name	Product code	Quantity					
1	Sink	HS800	1					
2	Drain cover	HF188x188	1					
3	Mounting bracket	SUZ	8					
4	Pan head screw	M4x6	8					
5	Mounting bracket	SU-21	6					
6	Truss head tapping screw	M4x18	6					
7	Flat washer	M4	6					
8	Skimless drainage set	-	1					
9	Basket	-	1					

Separately sold items						
No.	Product name	Product code	Quantity			
1	Bottle rack	SKA800-BR	1			
2	Drainer plate	SKA800-DP	1			
3	Cutting board	SKA800-CBS	1			

## ▲ Notices

- 1.  $\star\star\star$  It is applicable with counter thickness of more than 12mm.
- 2. Install the reinforcing plywood layer on the back and adhere it to the counter using epoxy adhesive.
- 3. Secure the sink and the plywood layer using 14 mounting brackets. Please note that there are two types of brackets are being used.
- 4. Apply modified silicone to the joint between the sink and the counter for waterproofing.
- 5. Adjust the dimensions of the plywood layer based on the sink's load bearing level, the counter dimensions and the cabinet dimensions.





